

BC-ST6

BC 3

GR 1-2

GR 3-4

GR 5-6

GR 7-8

PGM

0 1 2 3 4 5 6 7 8 9 10

TELCO SEND

TELCO FEED

PGM

TB-OFF

CUE

0 5 10 20 ±dB 20 10 5

L

R

LINE IN

0 1 2 3 4 5 6

AUX1

PRE

0 1 2 3 4 5 6

AUX2

PRE

0 1 2 3 4 5 6

AUX3

PRE

0 1 2 3 4 5 6

AUX4

PRE

0 1 2 3 4 5 6

L PAN R

CUE

POST

0 1 2 3 4 5 6

LEVEL

CUT

0 1 2 3 4 5 6 7 8 9 10

LPF

16 kHz

OFF

100

0 1 2 3 4 5 6 7 8 9 10

HPF

200 Hz

300 Hz

600 Hz

OFF

FILT

0 .2 .4 .6 .8 1 1.2 1.4 1.6 1.8 2

BASE

MNO C OVER

DIR

INP

MS

BASE

0 4 9 15 ±dB 15 9 4

HI

EQ

0 .3 .7 1.5

MID2

10 kHz

15 kHz

0 4 9 15 ±dB 15 9 4

MID1

15 kHz

0 .1 .25 1 2 3

MID1

2 kHz

3 kHz

0 4 9 15 ±dB 15 9 4

LOW

EQ

0 4 9 15 ±dB 15 9 4

BAL

BAL

REMOTE

PFL

CH-ON 24

PK

PS

FDR OPEN

