



PARALLEL INSTALLATION
EXTENSION-SELECT 3 IN

25 BU25/1+3 SRC17-20
25 BU25/2+4 SRC21-24

EXT-SEL-IN
EXT-SEL2/L-1/0 LEFT
BU-N1
EXTENSION-SELECT 3 IN/OUT
EXT-SEL2/R-1/0
BU-N2 RIGHT

IF EXT-SEL3 IS NOT INSTALLED BU-N1/N2 OPERATES AS INPUT FOR MAIN-EXT-SELECT

TB-EXT-MIC-IN
TB-EXT1-OUT
TB-EXT2-OUT
LISTEN-OUT
LISTEN-EXT-LINE-IN
LISTEN-EXT-MIC-IN
OSC-SWITCHED-OUT

TB/LISTEN-AUDIO 25 BU25/5
TB/LISTEN-AUDIO
TB/LISTEN-CTRL 25 ST25/1

EXT-LISTEN-CTRL-IN
EXT-MIC-CTRL-IN
EXT-TB-MIC-CTRL-IN
LISTEN-CTRL-OUT
ON-AIR-RELAIS-OUT
DIM-RELAIS-OUT
TB-RELAIS-OUT
AUTODIM-CTRL-IN
ON-AIR-CTRL-IN

USER-SW1-4 25 ST25/2

USER1
USER2
USER3
USER4

OSC-DIRECT-OUT ST-N3

CONTROL-BUSSES AND OUTPUT-RELAIS IN BASIC CONFIGURATION - CUSTOM VERSIONS POSSIBLE

Project	BC4	Object	BC-TBO4b	Rev.:	1	Material:	
Customer			Talkback - /Oscillator-Module	Ver.:	2	Surface:	
adT-audio (BS-2J)		Sheet Name	Block-Diagram	Sign:	Jg	Finish:	
BSH				Date:		Cutsize:	
				Upd.:		Marks:	
Dipl.-Ing. Cerd Jüngling, Scholtwiese 4-6, 45966 Gladbeck, Germany, Phone 02049 20 43 51061				Sheet 1 of 6			