

BC-STU4b BC4

SEL2

- SRC9
- SRC10
- SRC11
- SRC12
- SRC13
- SRC14
- SRC15
- SRC16

EXTENSION SOURCE

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 1

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 2

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

CTRL-ROOM FOLLOW

TB 0-6

PHONES 3

MONO, CUT

AUX 1, AUX 2, AUX 3, AUX 4

SRC-SEL, INT-SEL, CUE 1, PGM A

AUTO

TB 0-6

PHONES 4

MONO, DIM, AUTOCUT, CUT

ON VG 3 ON VG 4

dB

10, 5, 0, 5, 10, 15, 20, 25, 30, 40, 50, 60, 85, 00